


CSL Cpod Gen 4 RGBWA Remote Control



Master On/Off (Top Button all zones)
 (Note there are 4 zones that lights can be programmed to at the bottom of the control)

Color Mode:
 RGB Color Wheel

White mode:
 Color Temperature control sets White function:
 From Warm White to Cold White output

Mode Button Functions:
 Each number represents the number of times you press M for that function.
 Note: Indicator control led will flash

1. Red Flash
2. Color Fade
3. WW/CW Fade
4. RGBWA Fade
5. RGBWA Chase Sync
6. RGBWA Chase Random
7. Red Fade/Red Strobe
8. Green Fade/Green Strobe
9. Blue Fade/Blue Strobe

S+ Mode program Speed
 S- Mode program Speed

Saturation Control:
 Move to the up position for pastel color selections
 Move to the down position for pure color selections
 This is the master control that adds full color light spectrum (White and Amber) to any color wheel selection. The Saturation Control is always in effect.

Linking Instructions



When the light on, short press any zone of "1" **3 times** within 3 seconds

Green Led's will flash if linked
 Red if unlinked

Unlinking Instructions



2 When the light on, short press "1" **5 times** within 3 seconds

Unlinking must be the same zone with the Linking